


BWM PWC2500 Series

Spare Parts Diagram



Ref #	Parts No.	Description	QTY
1		BWM GT600 Or Honda GX200	1
2	HN53050AA	Adapter	1
3	BF70054AA360	Thermal Controller Drainage Pipe	1
4	HN23010BA	High Pressure Hose (3000PSI,10M)	1
5	HW19420BA	Label	1
6	HB52003AA	Panel Assembly	1
7	HB52001BB	Handle-Upper	1
8	HB21010AA	Handle Panel Bolt	4
9	N802A08B	Handle Panel Nut	14
10	HN13012AA	High Pressure Gun	1
11	B800B06X045B	Handle Bolt	4
12	N802A06B	Handle Nut	4
13	HB52005AA	Handle Adjuster	2
14	B801B08X020B	Pump Mounting Bolt	4
15	HB21010BA	Handle Supporting Bolt	8
16	HP12025BA	High Pressure Pump RCV3G25	1
17	HN33010AA035	Nozzle 0°	1
	HN33011AA035	Nozzle 15°	1
	HN33012AA035	Nozzle 25°	1
	HN33013AA035	Nozzle 40°	1
	HN33014AA	Soap Nozzle	1
18	HN43010AA	Nozzle Pad	5
19	HB52004AA	Support Bracket	1
20	GB41064AA	Support Pad	2
21	B800B08X025B	Support Pad Bolt	2
22	N802A14B	Wheel Nut	2
23	HB31030AA	Airless Tyre	2
24	HB52075AA	Wheel Bush	2
25	HB52061AA	Wheel Axle	1
26	N802A08B	Engine Mounting Nut	8
27	GB41070BA	Engine Anti Vibration Pad	4
28	HB51070AA	Base Plate	1
29	HB52002AA	Front Bumper	1
30	GW59061AC	Engine Oil Notice Card	1

Customer Service:

4 Kylie Place, Cheltenham, Victoria 3192, Australia

Telephone: 1300 454 585

Website: www.BWMachinery.com.au

Email: admin@bwmachinery.com.au

Spare parts are available from our dealers and our official website