


BWM PWC3600H Series

Spare Parts Diagram



Ref#	Parts No.	Description	QTY
1	BWMPWC3600H001	BWM GT1000 / Honda GX270	1
2	BWMPWC3600H002	Adapter NH3/4"-G3/4"	1
3	BWMPWC3600H003	Thermal Controller Drainage Pipe	1
4	BWMPWC3600H004	High Pressure Hose (4500PSI, 15M)	1
5	BWMPWC3600H005	Label	1
6	BWMPWC3600H006	Panel Assembly	1
7	BWMPWC3600H007-1	Handle-Upper	1
	BWMPWC3600H007-2	Handle-Lower	2
8	BWMPWC3600H008	Handle Panel Bolt M8x45	4
9	BWMPWC3600H009	Handle Panel Nut M8	14
10	BWMPWC3600H010	High Pressure Gun	1
11	BWMPWC3600H011	Handle Bolt M6x45	4
12	BWMPWC3600H012	Handle Nut M6	4
13	BWMPWC3600H013	Handle Adjuster	2
14	BWMPWC3600H014	Pump Mounting Bolt	4
15	BWMPWC3600H015	Handle Supporting Bolt M8x50	8
16	BWMPWC3600H016	High Pressure Pump RRV3.5	1
17	BWMPWC3600H017-1	Nozzle 0°	1
	BWMPWC3600H017-2	Nozzle 15°	1
	BWMPWC3600H017-3	Nozzle 25°	1
	BWMPWC3600H017-4	Nozzle 40°	1
	BWMPWC3600H017-5	Soap Nozzle	1
18	BWMPWC3600H018	Nozzle Pad	5
19	BWMPWC3600H019	Support Bracket	1
20	BWMPWC3600H020	Support Pad	2
21	BWMPWC3600H021	Support Pad Bolt M8x25	2
22	BWMPWC3600H022	Wheel Nut M14	2
23	BWMPWC3600H023	Airless Tyre	2
24	BWMPWC3600H024	Wheel Bush	2
25	BWMPWC3600H025	Wheel Axle	1
26	BWMPWC3600H026	Engine Mounting Nut M10	8
27	BWMPWC3600H027	Engine Anti Vibration Pad	4
28	BWMPWC3600H028	Base Plate	1
29	BWMPWC3600H029	Front Bumper	1
30	BWMPWC3600H030	Engine Oil Notice Card	1
31	BWMPWC3600H031	Inlet connector NH3/4"	1

Customer Service:

4 Kylie Place, Cheltenham, Victoria 3192, Australia

Telephone: 1300 454 585

Website: www.BWMachinery.com.au

Email: admin@bwmachinery.com.au

Spare parts are available from our dealers and our official website