

# Masport<sup>®</sup>

## Ride Ons

Product Number	Product Description
553386	TTM98SM



Issue A.0  
Aug 2024 TV  
ECN # 13005  
IPL Ref # 753386




## Table of Contents

Engine 432cc . . . . .	3
Chassis . . . . .	4
Hood & Fenders . . . . .	5
Deck 98 (1) . . . . .	6
Deck 98 (2) . . . . .	7
Electrical . . . . .	8
Suspension . . . . .	9
Drive Belt . . . . .	10
Pedal Controls . . . . .	11
Front Axle . . . . .	12
Steering . . . . .	13
Seat . . . . .	14
Fuel Tank . . . . .	15
Mulch Plug . . . . .	15




## Engine 432cc



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20084362	Knob, Choke	1	17	20085757	Bracket, Clutch Baffle	1
2	20051803	Screw, M4X16- Crsgroove PH	2	18	20061299	Bolt, Square Neck - M8X20	2
3	20061531	Washer, M4	2	19	20074428	Exhaust	1
4	20071241	Cable, Throttle	1	20	20060850	Screw, 5/16"-18-3/4"	3
5	LC1P90F-1	Eng Loncin LC1P90F-1 432cc	1	21	20061453	Spring Washer, 5/16"	3
6	20061285	Screw, St3/8"-16-11/4"	4	22	20061431	Washer, M8	1
7	20070519	Key, Flat - 6.35X30mm	1	23	20070868	Gasket, Exhaust	1
8	20070850	Pulley, Engine - 432cc	1	24	20071214	Muffler	1
9	20088530	Plate, Clutch	1	25	20084296	Plate, Muffler	1
10	20082800	Screw, M6X16 Hex	10	26	20061541	Washer, M8 - Large	2
11	20085206	Clutch,Electromag (Kokura)	1	27	20082799	Bolt,5/16-18Tx3/4 - Flange	2
12	20085758	Bushing, Clutch Step	1	28	20061346	Lock Nut, M6 - Flanged	2
13	20078309	Washer 12, Tapered- Engine	1	29	20071219	Cover, Exhaust	1
14	20062410	Bolt, 7/16"-20-3"	1	30	20061539	Washer, M6- Large	2
15	20085121	Plate, Clutch	1	31	20061184	Bolt, M6X26 - Hex	2
16	20061348	Lock Nut, M8 Hex Flanged	2				



## Chassis




Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20061274	Bolt, M8X20 - Hex Flanged	4	15	20085086	Bumper, Front	1
2	20084428	Bracket, Right Footrest	1	16	20061299	Bolt, Square Neck - M8X20	10
3	20061348	Lock Nut, M8 Hex Flanged	14	17	20084403	Bracket, Eng Cover - Left	1
4	20084430	Footrest, Right	1	18	20088532	Bumper Rod, LH	1
5	20084393	Pad, Foot - Right	1	19	20082800	Screw, M6X16 Hex	10
6	20061385	Lock Nut, M6 Flanged Hex	6	20	20084384	Brace, Steering Back Cover	2
7	20082799	Bolt, 5/16-18Tx3/4 - Flange	14	21	20084401	Frame, Steering Column	1
8	20084427	Frame, Support - Right	1	22	20061289	Bolt, M6X16 - Square Neck	2
9	20061201	Bolt, M6X16 - Hex Flanged	2	23	20084422	Frame, Support - Left	1
10	20070916	Bushing, Padded	2	24	20084429	Footrest, Left	1
11	20061196	Bolt, M6X25 - Hex Flanged	2	25	20084388	Pad, Foot - Left	1
12	20088080	Frame, Chassis	1	26	20084417	Frame, Seat - Front	1
13	20084375	Bracket, Eng Cover - Right	1	27	20084399	Side Plate	2
14	20088534	Bumper Rod, RH	1	28	20084414	Bracket, Left Footrest	1

When ordering spares: PLEASE QUOTE PART NUMBER & DESCRIPTION, NOT illustrated number. Item Qty = 1 per part unless stated differently. 'Acc' = Accessory. 'N/I' = Non-illustrated part. Descriptions starting with \* = items included in assemblies & may not be available individually. Determine the left or right hand sides by standing in the operating position. Page 4




## Hood & Fenders



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20061038	Screw, St4.8X16 Pan Head	27	20	20082800	Screw, M6X16 Hex	6
2	20084507	Wind Shroud	1	21	20084503	Cap, Steering Column	1
3	20084497	Screw, St4.8X20 Pan Head	2	22	20075146	Rubber, Anti-Vibration	4
4	20085132	Cover,Hood - Right RAL3020	1	23	20061013	Screw, M6X16- Crsgroove FH	3
5	20092325	Panel, Grille - Black	1	24	20084494	Panel, Dash- Upper	1
6	20070576	Spring Pin	2	25	20070630	Buckle Nut, M6	9
7	20061497	Washer, M10	2	26	20084495	Panel, Dash- Lower	1
8	20078136	Pin	2	27	20085126	Cover, Central - RAL3020	1
9	20084500	Cover, Right Light	1	28	20060893	Screw, M6X16 - Allen FH	2
10	20085780	Panel,Light Holder - Right	1	29	20060919	Screw M6X25	4
11	20084627	Board Assy, LED Light	1	30	20084298	Screw, St4.8X16 Hex Flng	2
12	20085735	Cover,Lights - Black Base	4	31	20091772	Cover- Fender,Rear-RAL3020	1
13	20051768	Screw, St2.9X12 Panhead	8	32	20084803	Cover, Gearbox	1
14	20085125	Cover, Left - Red RAL3020	1	33	20070780	Bushing	2
15	20085779	Panel, Light Holder - Left	1	34	20061274	Bolt, M8X20 - Hex Flanged	2
16	20084508	Cover, Left Light	1	35	20085165	Bushing - Tow Hitch	2
17	20050895	Clip, Ignition Wire	4	36	20085158	Tow Hitch	1
18	20085131	Cover,Engine - Red RAL3020	1	37	20061254	M8x40 Flanged Bolt - Tow Hitch	2
19	20085130	Cover, Air Intake RAL3020	1				




## Deck 98 (1)



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20086269	Cover, Belt - Right	1	17	20070624	Wash Port, Deck	2
2	20082801	Screw, St6.3X11.5 Hex	6	18	20055756	O-Ring, 11.2X2.65	2
3	20060893	Screw, M6X16 - Allen FH	7	19	20062521	Bolt,M10X1.25X40 Flnge Hex	1
4	20070630	Buckle Nut, M6	5	20	20084840	Plate,Deck Tension Pulleys	1
5	20070576	Spring Pin	2	21	20071180	Bushing, Pulley - Tension	1
6	20061544	Washer, M8X17X1.6mm	2	22	20071213	Pulley, Tensioner - Deck	1
7	20082335	Pin, D8X168mm	1	23	20061405	Nut, M10X1.25 Hex Flanged	1
8	20086192	Spring,Torsion-Dchrg Chute	1	24	20071680	V-Belt,48X900 (AKX2279) 98	1
9	20085378	Axle, Deck Wheel	2	25	20088529	Stop Rod, Deck Belt	1
10	20088559	Wheel, Deck- Rounded	2	26	20061336	Nut, Hex Flanged - M8	3
11	20061348	Lock Nut, M8 Hex Flanged	3	27	20086267	Cover, Belt - Left	1
12	20084843	Hinge, Discharge Chute	1	28	20070908	Pulley, Idler	1
13	20061385	Lock Nut, M6 Flanged Hex	7	29	20070898	Idler Spacer Sleeve	1
14	20086316	Cover, Pulley - Right	1	30	20070896	Washer, 17.3X55X4mm	1
15	20061359	Lock Nut,M12X1.25 Hex Flng	2	31	20060923	Screw, M6X12 Allen FH	1
16	20070897	Counterbore Sleeve	1	32	20086315	Cover, Pulley - Left	1




## Deck 98 (2)



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
33	20070899	Shaft, Idler Pulley	1	49	20061541	Washer, M8 - Large	1
34	20070875	Spring, Tension	1	50	20061249	Bolt, M6X30 - Square Neck	2
35	20084542	Screw, Adjustment - Deck	1	51	20088737	Plate- Spindle, Deck	2
36	20084846	Deck, 98cm - Black	1	52	20061265	Bolt M8X35, Flanged	8
37	20070627	Nut, Spindle	2	53	20070984	Blade, 49cm	2
38	20070638	Pulley, Blade	2	54	20070623	Washer, Blade	2
39	20061650	Key, Flat - 6X18mm	2	55	20061497	Washer, M10	2
40	20070622	Shaft, Spindle - Blade	2	56	20061267	Bolt, 3/8"-24-11/4" (10.9)	2
41	20071285	Cover, Bearing-Spndl Up	2	57	20051827	Screw, St4.8X13 PH	1
42	20061625	Bearing, Spindle 6204-2RZ	4	58	20061289	Bolt, M6X16 - Square Neck	2
43	20054347	Housing, Spindle	2	59	20061301	Bolt, M6X25 Square Neck	1
44	20061488	Snap Ring, 19mm	2	60	20086275	Pin, Self-Locking	1
45	20070635	Cover, Bearing-Spndl Low	2	61	20086276	Spring, Torsion-Self Lockin	1
46	20061651	Key, Half Circle - 4X16mm	2	62	20086278	Buckle, Self-Lock RAL3020	1
47	20054345	Coupling, Blade	2	63	20086277	Base, Self-Locking - Black	1
48	20070892	Stud, Screw	1	64	20086249	Discharge Chute, Black	1



## Electrical




Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20085496	Cable, Battery-Ground	1	15	20087086	Mounting Plate, Hour Meter	1
2	20092359	Wiring Harness	1	16	20081704	Hour Meter	1
3	20051895	Cable Tie, 5X200mm	20	17	20087039	Screw M3X12 - Pan Head	2
	20086002	Cable Tie	5	18	20084633	Washer, M3 - Serrated	6
4	20062416	Cover, Switch	1	19	20061334	Nut, Switch - Hex M3	4
5	20089224	Switch, Parking	1	20	20085696	Fuse, 20A	1
6	20084624	Cable, Battery-Positive	1	21	20062234	Switch, PTO	1
7	20061186	Bolt, Flanged M5X16	2	22	20089045	Switch - Reverse Cutting	1
8	20071221	Starter Relay ST188F	1	23	20089345	Switch - Ignition	1
9	20061341	Lock Nut, M5 Hex Flanged	2	24	20089223	Clamp, Wire	1
10	20089006	Relay YAP23H-12-HR	2	25	20086270	Switch, 2 Pin-Nrmly Clsd	1
11	20089880	Nut M5- Clip	1	26	20070744	Strap, Battery	1
12	20062522	Screw M5X12 Hex	1	27	20071324	Battery-12V18Ah	1
13	20084637	Cable, Starter	1	28	20084632	Hook, Battery Strap	2
14	20082800	Screw, M6X16 Hex	4				






## Suspension



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20061348	Lock Nut, M8 Hex Flanged	4	17	20084726	Pull-Rod, Lifting Lever	1
2	20061541	Washer, M8 - Large	4	18	20082800	Screw, M6X16 Hex	2
3	20084556	Stay Bar, Front 98	2	19	20085316	Plate, Height Adj Spring	1
4	20084557	Boom, Front Right	1	20	20070900	Handle, Cutting Height	1
5	20061369	Nut, M10X1.25 - Flanged Hex	3	21	20084549	Ratchet Plate, Height Adj	1
6	20084533	Pin, Front Susp	1	22	20084564	Spring, Tension-Height Adj	1
7	20061405	Nut, M10X1.25 Hex Flanged	4	23	20071251	Cotter Pin, 3mm	1
8	20061497	Washer, M10	10	24	20062529	Washer, M14 X 1.5	1
9	20070576	Spring Pin	10	25	20071354	Torsion Spring, Height Lvr	1
10	20084722	Linkage, Front-Rear Height	1	26	20084535	Lever, Height Adjustment	1
11	20084723	Rear Arm	1	27	20061473	Circlip, 12mm	1
12	20084553	U-Linkage, Front Arms	1	28	20070612	Bushing, Hex- Steering	2
13	20084560	Front Arm	1	29	20084537	Linkage, Deck Lift - Rear	1
14	20082799	Bolt, 5/16-18Tx3/4 - Flange	10	30	20085750	Pin, Connector - Plated	2
15	20084532	U-Bracket, Brake Bar	4	31	20084727	Lever, Adjusting Left Rear	1
16	20070967	Pin, Height Adjuster	1	32	20085749	Lever, Adjustment Right Rear	1




## Drive Belt



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20070581	Pin, Gear Shifter 98Sm	1	18	20061321	Bolt M10X1.25X45-Flngd	1
2	20084436	Spacer Sleeve, 8X18X33mm	1	19	20082800	Screw, M6X16 Hex	4
3	20061385	Lock Nut, M6 Flanged Hex	1	20	20084715	Baseplate-Guide Pulley	1
4	20061275	Bolt, M8X60 - Hex Flanged	1	21	20084712	Sleeve- Guide Pulley	1
5	20084713	Guide,Belt- Left Front	1	22	20061542	Washer, M10 - Large	1
6	20070780	Bushing	2	23	20062499	Washer, 27X10.5X5	1
7	20061289	Bolt, M6X16 - Square Neck	1	24	20084441	Bolt,Tension Pulley-Drive	1
8	20062521	Bolt,M10X1.25X40 Flnge Hex	1	25	20062515	Bolt,M10X1.25X50 Flnge Hex	2
9	20090612	Weldment, Tension Arm	1	26	20071208	Pulley, Guide - Drive	3
10	20061336	Nut, Hex Flanged - M8	1	27	20070536	Pulley, Tensioner	1
11	20070576	Spring Pin	2	28	20061626	Bearing,6301-2RS-Tensioner	1
12	20071180	Bushing, Pulley - Tension	1	29	20061549	Snap Ring, 37mm	1
13	20062716	Washer 8X16X1.5	2	30	20084444	V-Bolt LG4-1050 (HA2645)	1
14	20084710	Linkage Push Rod	1	31	20084442	Sleeve, Guide Pulley	2
15	20071213	Pulley, Tensioner - Deck	1	32	20084716	Belt Guide- RHS	1
16	20061403	Lock Nut, M10X1.25 - Hex	6	33	20084709	Belt Guide- LHS	1
17	20070875	Spring, Tension	1				



## Pedal Controls




Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20068187	Hub Cap	2	25	20070581	Pin, Gear Shifter	1
2	20061430	Circlip, 15mm	2	26	20061473	Circlip, 12mm	1
3	20071143	Washer, Wheel - 20X43X3mm	4	27	20084686	Axle Pin- Gear Lever	1
4	20086530	Wheel Assy, Rear- 18X8.5-8	2	28	20084702	Spring-Torsion 3.5X20	1
4.1	20061665	VLve,Z2-01-1,Gb/T3900-1997	2	29	20084692	Lever- Gear Shift	1
4.2	20060810	Rim, Rear Wheel	2	30	20070900	Handle, Cutting Height	1
4.3	20083979	Tyre, Rear - 18X8.5-8	2	31	20084700	Pin- Brake Lever	1
5	20071174	Key, Flat - 4.85X60mm	2	32	20084705	Plate- Brake Adjust	1
6	20092354	Transmission	1	33	20084706	Spring-Compress 2.5X14	1
7	20084693	Connecting Plate-G/Box	1	34	20061393	Nut M8	1
8	20082799	Bolt,5/16-18Tx3/4 - Flange	5	35	20082800	Screw, M6X16 Hex	2
9	20061309	Bolt M8X16, Flanged	1	36	20089015	Fixing Plate, Brake Switch	1
10	20061348	Lock Nut, M8 Hex Flanged	8	37	20084532	U-Bracket, Brake Bar	2
11	20061310	Bolt, M8X65 - Hex Flanged	4	38	20073313	Washer- ID 16.5 X OD 30 X 1.5	1
12	20070576	Spring Pin	3	39	20061482	Washer, M6	1
13	20089122	Rod- Gear Shift	1	40	20070582	Cotter Pin	3
14	20061539	Washer, M6- Large	1	41	20061250	Bolt M8X30, Flanged	1
15	20061487	Spring Washer- 6	1	42	20088842	Flanged Insert	1
16	20061273	Bolt 1/4"-28-3/4"	1	43	20090105	Plate- Parking Hook	1
17	20084699	Gear Shifter Arm	1	44	20061541	Washer, M8 - Large	1
18	20070884	Pulley- Transmission	1	45	20090104	Drag Link-Park Brake	1
19	20061434	Circlip-16,Trans Pulley	1	46	20070894	Spring, P.Brake Reset	1
20	20084684	Brake Lever	1	47	20084583	Handle, Pbrake - RAL3020	1
21	20061426	Washer- 8	3	48	20084581	U-Bolt, Handle-Brake	1
22	20083999	Bolt M8X80, Flanged	1	49	20088848	Weldment-Foot Brake	1
23	20084697	Weldment- Gear Lever	1	50	20082728	Pedal, Brake	1
24	20061359	Lock Nut,M12X1.25 Hex Flng	1				

When ordering spares: PLEASE QUOTE PART NUMBER & DESCRIPTION, NOT illustrated number. Item Qty = 1 per part unless stated differently. 'Acc' = Accessory. 'N/I' = Non-illustrated part. Descriptions starting with \* = items included in assemblies & may not be available individually. Determine the left or right hand sides by standing in the operating position.




## Front Axle



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20068187	Hub Cap	2	10	20061348	Lock Nut, M8 Hex Flanged	1
2	20061488	Snap Ring, 19mm	2	11	20070941	Steering Arm	1
3	20071143	Washer, Wheel - 20X43X3mm	2	12	20091656	Washer 8X30X3- Front Axle	2
4	20071144	Washer, Front Wheels	4	13	20061533	Spring Washer, 8mm	2
5	20086529	Wheels, Front - 15X6-6	2	14	20061291	Bolt, M8X20	2
5.1	20083980	Tyre, Front - 15X6-6	2	15	20061256	Bolt, M8X45 - Hex Flanged	1
5.2	20071149	Hub, Wheels - Front	2	16	20061359	Lock Nut, M12X1.25 Hex Flng	1
5.3	20061665	Vlve, Z2-01-1, Gb/T3900-1997	2	17	20084370	Liner Tube, Front Axle	1
5.4	20061595	Bearing, 61904-2RZ - F/Wheel	4	18	20061649	Nozzle, Oil Injection - M6	2
6	20084372	Axle, Wheel - Front Left	1	19	20061482	Washer, M6	2
7	20061444	Washer, M20-Front Axle	2	20	20085752	Bolt, M12X1.25X55 Flanged	1
8	20070566	Bushing, Front Axle	4	21	20084367	Axle, Wheel - Front Right	1
9	20084364	Linkage, Front Axle	1				




## Steering



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20085366	Joint Bearing,M10-Steering	1	18	20061437	Washer, M16-Steering Rack	2
2	20061399	Nut, M10 - Drag Link	2	19	20070612	Bushing, Hex- Steering	1
3	20084461	Drag Rod, Steering	1	20	20071127	Bushing, Nylon	1
4	20061348	Lock Nut, M8 Hex Flanged	7	21	20085898	Retaining Block, 16mm	1
5	20084463	Plate, Steering	1	22	20070939	Tie Plate, SS	1
6	20061299	Bolt, Square Neck - M8X20	2	23	20070932	Bushing, Steering Plate	2
7	20061298	Bolt, M8X25 Flanged Hex	6	24	20084464	Rack, Steering	1
8	20083389	Coupling Sleeve, Steering	1	25	20070942	Plate, Dbl Hole -Steering	1
9	20082643	Bushing, Nylon	1	26	20061641	Joint Bearing, SIJK10C	1
10	20061548	Circlip, 15mm	1	27	20061403	Lock Nut, M10X1.25 - Hex	1
11	20084458	Column, Steering	1	28	20084465	Adapter, Steering Wheel	1
12	20061419	Lock Nut, M10- Hex	1	29	20051824	Screw, St4.8X16 Pan Head	2
13	20084462	Bush, Rubber - Tie Rod	2	30	20082707	Wheel, Steering-Rubber Blk	1
14	20084456	Tie Rod, Steering	1	31	20079969	Hub, Splined - S/Wheel	1
15	20084459	Screw, M8X28	2	32	20082683	Washer, Steering Wheel	1
16	20084457	Pinion, Steering	1	33	20082679	Cover, S/Wheel RAL3020	1
17	20061569	Pin, D6 X 26	1				



## Seat




Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20061348	Lock Nut, M8 Hex Flanged	6			Serial Numbers < 4J05-000001	
2	2008447	Crossbeam, Support - Seat	1	15	20088757	Seat, V2	
3	20061274	Bolt, M8X20 - Hex Flanged	2	16	20085377	Spring- Seat Adj Plate	1
4	20070964	Spring, Compression - Seat	2	17	20085375	Seat Adjuster	1
5	20061541	Washer, M8 - Large	6				
6	20061298	Bolt, M8X25 Flanged Hex	6				
7	20068240	Cap, Spring - Seat	2			Serial Numbers > 4H20-000084	
8	20085449	Baseplate-Seat,Adjustable	1	13	20062556	Screw, M8X20 - Hex Socket	4
9	20088755	Screw, Baseplate- Seat	2	14	20091256	Plate, Seat Switch	1
10	20088754	Padding Strip, Seat	2	15	20092693	Seat, ZJZY2-3 V3	1
11	20082800	Screw, M6X16 Hex	2	16	20091602	Spring- V3 Seat Adj Plate	1
12	20088756	Switch, Seat V.2	1	17	20092317	Adjuster Plate, V3 Seat	1
						To Replace V2 With V3 Seat:	
					20093970	Assembly 13-17	

When ordering spares: PLEASE QUOTE PART NUMBER & DESCRIPTION, NOT illustrated number. Item Qty = 1 per part unless stated differently. 'Acc' = Accessory. 'N/I' = Non-illustrated part. Descriptions starting with \* = items included in assemblies & may not be available individually. Determine the left or right hand sides by standing in the operating position.




## Fuel Tank



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20059754	Lever, Fuel Tank Cap	1	9	20059765	Cotter Pin, Fuel Tank Cap	1
2	20071493	O-Ring, Cap - Fuel Tank	1	10	20059766	Filter Cap, Fuel Tank	1
3	20059760	Cap, Fuel Tank	1	11	20071228	Fuel Tank	1
4	20059763	Filter Element, F/Tank Cap	1	12	20082800	Screw, M6X16 Hex	3
5	20090126	Seal, Fuel Tank Cap- V.2.	1	13	20062744	Clamp, Fuel Hose D10mm	1
6	20071676	Gasket, 6X25X1.5mm	4	14	20070865	Fuel Hose, D6X10mm	1
7	20059764	Spring, Fuel Tank Cap	1	15	20071161	Clamp, Dw-Fuel Hose D10mm	1
8	20061445	Washer, M5	1	16	20071747	Cap Assy, Fuel Tank	

## Mulch Plug



Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	20061423	Nut M6X13.5	2	5	20061539	Washer, M6- Large	2
2	20061542	Washer, M10 - Large	2	6	543623	Mulch Plug	1
3	20071033	Hook, Mulch Plug	2	7	20061013	Screw, M6X16- Crsgroove FH	2
4	20071032	Strap, Mulch Plug	2				

When ordering spares: PLEASE QUOTE PART NUMBER & DESCRIPTION, NOT illustrated number. Item Qty = 1 per part unless stated differently. 'Acc' = Accessory. 'N/I' = Non-illustrated part. Descriptions starting with \* = items included in assemblies & may not be available individually. Determine the left or right hand sides by standing in the operating position.