


BWM PWC4200H Series

Spare Parts Diagram



Ref#	Parts No.	Description	QTY
1	BWMPWC4200H001	BWM GT1300 / Honda GX390	1
2	BWMPWC4200H002	Adapter NH3/4"-G3/4"	1
3	BWMPWC4200H003	Thermal Controller Drainage Pipe	1
4	BWMPWC4200H004	High Pressure Hose (4500PSI, 15M)	1
5	BWMPWC4200H005	Label	1
6	BWMPWC4200H006	Panel Assembly	1
7	BWMPWC4200H007-1	Handle-Upper	1
	BWMPWC4200H007-2	Handle-Lower	2
8	BWMPWC4200H008	Handle Panel Bolt M8x45	4
9	BWMPWC4200H009	Handle Panel Nut M8	14
10	BWMPWC4200H010	High Pressure Gun	1
11	BWMPWC4200H011	Handle Bolt M6x45	4
12	BWMPWC4200H012	Handle Nut M6	4
13	BWMPWC4200H013	Handle Adjuster	2
14	BWMPWC4200H014	Pump Mounting Bolt	4
15	BWMPWC4200H015	Handle Supporting Bolt M8x50	8
16	BWMPWC4200H016	High Pressure Pump RRV4G40	1
17	BWMPWC4200H017-1	Nozzle 0°	1
	BWMPWC4200H017-2	Nozzle 15°	1
	BWMPWC4200H017-3	Nozzle 25°	1
	BWMPWC4200H017-4	Nozzle 40°	1
	BWMPWC4200H017-5	Soap Nozzle	1
18	BWMPWC4200H018	Nozzle Pad	5
19	BWMPWC4200H019	Support Bracket	1
20	BWMPWC4200H020	Support Pad	2
21	BWMPWC4200H021	Support Pad Bolt M8x25	2
22	BWMPWC4200H022	Wheel Nut M14	2
23	BWMPWC4200H023	Airless Tyre	2
24	BWMPWC4200H024	Wheel Bush	2
25	BWMPWC4200H025	Wheel Axle	1
26	BWMPWC4200H026	Engine Mounting Nut M10	8
27	BWMPWC4200H027	Engine Anti Vibration Pad	4
28	BWMPWC4200H028	Base Plate	1
29	BWMPWC4200H029	Front Bumper	1
30	BWMPWC4200H030	Engine Oil Notice Card	1
31	BWMPWC4200H031	Inlet connector NH3/4"	1
32	BWMPWC4200H032	Rotatung Turbo Nozzle 040 5000psi Max	1

Customer Service:

4 Kylie Place, Cheltenham, Victoria 3192, Australia

Telephone: 1300 454 585

Website: www.BWMachinery.com.au

Email: admin@bwmachinery.com.au

Spare parts are available from our dealers and our official website