


BWM PWC3200H Series

Spare Parts Diagram



Ref#	Parts No.	Description	QTY
1	BWMPWC3200H001	BWM GT600 / Honda GX200	1
2	BWMPWC3200H002	Adapter NH3/4"-G3/4"	1
3	BWMPWC3200H003	Thermal Controller Drainage Pipe	1
4	BWMPWC3200H004	High Pressure Hose (3500PSI, 10M)	1
5	BWMPWC3200H005	Label	1
6	BWMPWC3200H006	Panel Assembly	1
7	BWMPWC3200H007-1	Handle-Upper	1
	BWMPWC3200H007-2	Handle-Lower	2
8	BWMPWC3200H008	Handle Panel Bolt M8x45	4
9	BWMPWC3200H009	Handle Panel Nut M8	22
10	BWMPWC3200H010	High Pressure Gun	1
11	BWMPWC3200H011	Handle Bolt M6x45	4
12	BWMPWC3200H012	Handle Nut M6	4
13	BWMPWC3200H013	Handle Adjuster	2
14	BWMPWC3200H014	Pump Mounting Bolt	4
15	BWMPWC3200H015	Handle Supporting Bolt M8x50	8
16	BWMPWC3200H016	High Pressure Pump RCV2.5G30	1
17	BWMPWC3200H017-1	Nozzle 0°	1
	BWMPWC3200H017-2	Nozzle 15°	1
	BWMPWC3200H017-3	Nozzle 25°	1
	BWMPWC3200H017-4	Nozzle 40°	1
	BWMPWC3200H017-5	Soap Nozzle	1
18	BWMPWC3200H018	Nozzle Pad	5
19	BWMPWC3200H019	Support Bracket	1
20	BWMPWC3200H020	Support Pad	2
21	BWMPWC3200H021	Support Pad Bolt M8x25	2
22	BWMPWC3200H022	Wheel Nut M14	2
23	BWMPWC3200H023	Airless Tyre	2
24	BWMPWC3200H024	Wheel Bush	2
25	BWMPWC3200H025	Wheel Axle	1
26	BWMPWC3200H026	Inlet connector NH3/4"	1
27	BWMPWC3200H027	Engine Anti Vibration Pad	4
28	BWMPWC3200H028	Base Plate	1
29	BWMPWC3200H029	Front Bumper	1
30	BWMPWC3200H030	Engine Oil Notice Card	1

Customer Service:

4 Kylie Place, Cheltenham, Victoria 3192, Australia

Telephone: 1300 454 585

Website: www.BWMachinery.com.au

Email: admin@bwmachinery.com.au

Spare parts are available from our dealers and our official website